





Download the Mirana App Now 🔊 💰



USB RECHARGEABLE







SMOOTH SUSPENSION



LUMINOUS HEAD LIGHT



FULL



BRIGHT TAIL LIGHT



MOBILE CONSOLE



SCALE



BLUETOOTH CONTROLLED











FOR AGES 4 & ABOVE

For detailed support & information, visit our website

www.miranatoys.com

1. DOWNLOADING THE MIRANA APP & INSTALLATION


- 1. Go to App Store or Play Store
- 2. Search "MIRANA" App
- 3. Download & Install it Free!
- 4. You are ready to explore

2. BUILT-IN BATTERY

The Mirana App-Controlled Ranger comes with a rechargeable 1200 mAH battery. Don't attempt to modify, remove or replace the battery as it may damage it and cause overheating and injury. Don't cut, tear, puncture, compress or deform the Mirana App-Controlled Ranger by disassembling it.

Follow the below instructions for charging its battery:


- 1. Turn the Ranger upside down to check the charging port
- 2. Plug the USB charging cable provided in the box into the (5V-2A) DC input charging slot at the bottom of the Ranger
- Red LED will glow up while charging
- Green LED will glow up when Ranger is fully charged
- 3. Remove the adapter when the Green LED glows up





3. PLAYING INSTRUCTIONS

- 1. Turn on the power switch of the Mirana App-Controlled Ranger given at its bottom
- 2. Switch on the Bluetooth of your mobile phone and open the Mirana App installed on your phone
- 3. Long press the Bluetooth button given at the bottom of your Mirana App-Controlled Ranger till it turns on
- 4. Your Mirana App-Controlled Ranger and the Mirana App are connected now
- 5. Use the App enabled console to drive the toy car
- 6. For directional control, use the left round button on the console screen for moving the vehicle forward and backwards. Use the right round button for turning left or right
- 7. For an extra burst of speed, you can use the (energy symbol) button on the left side situated above the round button to activate the Boost function
- 8. Use the headlights button for switching on the headlights of the toy car
- 9. Use the (rocket) button on both the sides to perform stunts
- 10. To exit the game press on the exit button in top left corner



4. CARE AND MAINTENANCE

Keep it away from direct sunlight, high humidity, high temperature or excess heat. Ensure that the tires are clean for optimized grip. Gently wipe the tires with a damp cloth whenever they become dirty. Do not immerse the Ranger or any part of it in water to clean it. This can damage its electronic components. Before using the toy car, please ensure that it is not damaged and safe to use.

SAFETY PRECAUTIONS

The App Controlled Ranger should be used by children aged 4 years or above. While using it for the first time, this toy car should be safely set up under adult supervision. Do not try to modify any part of the Ranger, which may negate your authority to use it. Rechargeable batteries of this toy car should be charged under adult supervision only. While charging the Ranger, do not touch the electric outlet and the charging port with bare/wet hands to avoid electric shock. Do not use damaged electric outlets for charging batteries. Adults should examine the USB cable, plug, enclosure or other parts of the Ranger regularly. Strictly adhere to this instruction manual while operating the App Controlled Ranger.

DISPOSAL IINFORMATION

Never dispose of the App Controlled Ranger along with the household waste. If / When you decide to dispose of this toy car, discard it in e-waste container that are in accordance with the local environmental laws, guidelines and battery recycling procedures.





FOR KIDS

Scan this QR Code to Download Now



Manufactured by:

MIRANA INNOVATIONS PRIVATE LIMITED

201, Plot No. T33, T Block, MIDC Road, Bhosari, Pune, MH, India - 411 026. For Feedback and complaints, contact us at support@miranatoys.com

www.miranatoys.com









